

# USB TYPE-C TO 5G ETHERNET ADAPTER



Windows



**WINDOWS  
MAC  
LINUX**  
COMPATIBLE

USB




5GBPS

ETHERNET



## WINDOWS DRIVER UPDATE OR INSTALL VIA WINDOWS UPDATE

Updating the driver for the NT-C5GA is as simple as running a routine Windows Update after connecting it. To do so, please follow the instructions below.



- 1 Open Settings on your Windows computer by pressing Windows key + I or by right-clicking the Start button and selecting Settings.
- 2 Navigate to and select Windows Update on the left sidebar.
- 3 Select Check for updates, and Windows will automatically search for and install available driver updates for this device.
- 4 Once installation is complete, restart your computer to apply the changes.

## MANUAL WINDOWS DRIVER INSTALLATION

If you are unable to use Windows Update, manually updating the driver for the NT-C5GA is nearly just as simple. To do so, please follow the instructions below.

|   REALTEK <input type="text" value="搜尋"/>   English  |                                                        |                        |             |           |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|------------------------|-------------|-----------|
| Windows                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                        |                        |             |           |
| Download                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Description                                            | Version                | Update Time | File Size |
|                                                                                                                                                                                                                                                                                                                                                                                          | Win11 Auto Installation Program (NetAdapterCx)         | 1153.20.20, 115X.19.20 | 2025/09/16  | 6 MB      |
|                                                                                                                                                                                                                                                                                                                                                                                          | Win10 Auto Installation Program                        | 10.65.20.0603          | 2025/07/31  | 5 MB      |
|                                                                                                                                                                                                                                                                                                                                                                                          | Ethernet Diagnostic Program for Win7/Win8/Win10/Win11  | 2.0.8.1                | 2024/09/25  | 7 MB      |
|                                                                                                                                                                                                                                                                                                                                                                                          | Win7 and Server 2008 R2 Auto Installation Program      | 7.61.20                | 2021/12/28  | 5 MB      |
|                                                                                                                                                                                                                                                                                                                                                                                          | Win8, Win8.1 and Server 2012 Auto Installation Program | 8.66.20                | 2021/12/28  | 5 MB      |
|                                                                                                                                                                                                                                                                                                                                                                                        | WinXP Auto Installation Program for FE/GBE             | 5.23                   | 2021/07/27  | 9 MB      |
|                                                                                                                                                                                                                                                                                                                                                                                        | Vista and Server 2008 Auto Installation Program        | 6.27                   | 2018/08/02  | 9 MB      |


- 1 Visit Realtek's official driver download page for the RTL8157 chip and download the latest driver:

[https://www.realtek.com/Download/List?cate\\_id=585](https://www.realtek.com/Download/List?cate_id=585)

- 2 Run the downloaded driver installer following the on-screen prompts to complete the installation. Once the installation finishes, restart the computer to apply the changes.

## MANUAL WINDOWS DRIVER REMOVAL

Driver removal is sometimes a necessary step in troubleshooting and diagnosing networking issues. To do so, please follow the instructions below.



- 1 Right-click the Start button and select Device Manager. Once open, expand the Network adapters.
- 2 Right-click Realtek USB 5GbE Family Connector and select Uninstall device.
- 3 In the uninstall prompt, check the box for Attempt to remove the driver for this device, then click Uninstall.
- 4 After the uninstall process finishes, restart the computer. Reinstall the driver via Windows Update or by following the manual installation steps above.



FOR HELP, COMMENTS, QUESTIONS OR CONCERNS  
PLEASE CONTACT OUR TECH SUPPORT TEAM VIA OUR WEBSITE  
**[WWW.SABRENT.COM](http://WWW.SABRENT.COM)**